



Instructions for Qualatex® X- Pattern Wall

To keep assembly time to a minimum, gather the materials and read through the instructions before beginning.


Labor: About 1 Hour

Materials:

- 68 12" (30cm) White Quick Link Balloons™ 64151
- 32 12" Yellow Quick Link Balloons 65214
- 40 5" (13cm) White Latex Balloons 43607
- 34 5" Orange Latex Balloons 43570
- 16 5" Lime Green Latex Balloons 48954
- 8 5" Yellow Latex Balloons 43609
- Monofilament (Fishing) Line

Instructions:

1. Inflate two White Quick Links to 9" (23cm) and tie together into a pair. Repeat to make another pair. Twist both pairs together to make a 4-balloon cluster (see Figure A on page 2).






Figure A




Figure B

2. Inflate two 5" Orange latex to 3.5" (9cm) and tie into a pair. Wrap this pair into the center of the cluster from Step 1, so that one Orange balloon is on the front and one is on the back.
3. Repeat Steps 1-2 to make 16 more White Quick Link clusters with Orange centers.
4. Inflate eight 4-balloon clusters of Yellow Quick Links sized to 9". Inflate eight pairs of 5" Lime Green latex sized to 3.5", and wrap each pair into the center of a Quick Link cluster.
5. Using the tips of the Quick Links, tie together five White clusters side-by-side to make the top row of the wall (**see Figure B**). Follow the colors and pattern shown to make the remaining four rows of Quick Link clusters.
6. Inflate 12 pairs of 5" White latex sized to 3.5", and four pairs of 5" Yellow latex sized to 3.5". Connect all the rows from Step 5 together by wrapping a pair around the Quick Link knots between each row as shown in the photo. Make sure to twist the 3.5" balloons completely around each other to lock them in place, positioning one on the front and one on the back.
7. Tie the tips of the Quick Links together all around the outer border of the wall. Carefully trim the excess tips.
8. Inflate four 4-balloon clusters of 5" White latex sized to 3.5". Tie one cluster onto each corner of the wall using the Quick Link tip.
9. Suspend with monofilament line.

TIPS

- Promote Quick Link walls for photo backdrops, stage backdrops, entrance decor, and more.
- Use the Conwin Precision Air® to precisely inflate two balloons at a time, ensuring consistent sizing and professional results.
- Make the wall larger or smaller as needed by adjusting the quantity and/or the inflated size of the Quick Links.
- Apply Balloon Shine™ to prevent oxidation and keep the balloons looking fresh longer.
- Change the latex colors and experiment with different patterns to coordinate with any theme.
- Use grid paper or a computer program to determine patterns and colors before you start. A blank template for this style of wall is provided on QualatexQuickLinks.com.

Find more design ideas with Qualatex® Quick Link Balloons™ at QualatexQuickLinks.com. Other ideas and instructions are available to professionals at "Instruction Sheets" and "Balloon Ideas" on qualatex.com.



WARNING:

CHOKING HAZARD

Children under 8 years can choke or suffocate on uninflated or broken balloons. Adult supervision required. Keep uninflated balloons from children. Discard broken balloons at once.

For Consumer Product Information, visit pioneerpci.com or call 1-800-331-6865.

